

Together,
Let's do more!

Tips & Tricks

Beauty Now And Beyond



ZIMMER BIOMET
Your progress. Our promise:

Aanbevolen momentkracht (Ncm)

Zimmer Torque Wrench



Momentkracht

- Healingcollars en afdruktiften: **handvast**
- Alle abutments die definitief in het implantaat geplaatst worden: **30Ncm**
- Locator abutments: **30Ncm**
- Fixatieschroeven die in Tapered TAC abutments worden geschroefd: **20Ncm**



HXGR 1.25 (handtool)



TW1.25 torque tool)



LOCTW1.25 torque Locatortool)